



Material moisture meter with temperature display 30.5506.01

Highlights & Details

Highlights:

- Moisture measuring instrument for wood, timber and other construction materials
- Ideal for measuring the moisture of wood
- With indication of temperature
- Measured values displayed as a graph
- Easy to use and robust housing

Product specification

With the moisture measuring instrument you can easily and quickly measure the moisture content of firewood, timber, or other building materials.

This robust instrument is ideal for on-site inspection at the construction site or on new construction. The operation is very simple – remove the protective cap and insert the measuring electrodes into the object to be measured – finished. The handy device has a measuring scale for building materials and wood. Especially important is the measurement of the moisture content of firewood before using it in the fireplace. As wood cells have more than 20% water content, this leads to not only a decrease in calorific value, but also to smoke, tar and soot formation.

Function

- **For measuring the moisture of wood and construction materials**
- **With indication of temperature**
- **Easy to use**
- **Robust housing**
- **Scale for construction material and wood**
- **Automatic switch-off**
- **Illumination LED.**
- **With protection cap and clip for fixing.**

Technical data

Measuring range	Wood moisture: 6...44%, Material moisture: 0,2...2%
------------------------	--

Delivery contents	Moisture measuring instrument, instruction manual
Measuring range temperature	0 ... +40°C (+32 ... 104°F)
Material	Plastic
Power consumption	Batteries
Batteries included	no
Batteries	4 x AAA 1.5 V
Dimensions	(L) 44 x (B) 34 x (H) 144 mm
Weight	103 g