

## Model- Ph-300



Ph-300 Meter, Digital 4 in 1 PH EC TDS Temp Meter for Water Hydroponics, Waterproof and EC PPM Water Tester with Backlight for Laboratory, Nutrients..

- 4-in-1 Mode With INKBIRDPLUS 4-in-1 pH-300 tester, you can accurately measure pH, TDS(ppm), EC( $\mu\text{S}/\text{cm}$  /  $\text{mS}/\text{cm}$ ), and temp value, and know water quality clearly to ensure your family member's health.
- 【High Accuracy With the highly sensitive probe, you can get a full measurement range of 0-14pH, 0.01 pH resolution, and the pH meter uses a 3-point calibration method to calibrate the electrode to

solutions of pH 4.00, pH 6.86, and pH 9.18. You can calibrate effortlessly to ensure the accuracy of your measurements.

- **【Automatic Temperature Compensation** With the ATC function, the 4-in-1 pH meter solves the inaccurate measuring problem caused by the change of liquid temperature; Backlit LCD Design guarantees that you can read the measuring results in any condition, easily to get a reliable, stable reading.
- **【Easy to Use** After calibration put the sensor into the solution you want to test, and get the data immediately, before another test, wash the probe carefully; Or you may get an inaccurate reading.
- **Wide Application】** Ideal for household and laboratory testing applications, for drinking water, beer, and kombucha testing, and good for aquariums, ponds in a garden, bathtub, and swimming pool use, too.