



HOW PURE  
IS YOUR WATER?®



## AP-1: AQUAPRO WATER QUALITY TESTER (TDS)

*HM Digital introduces its new AquaPro series, a line of handheld TDS/EC meters with a sleek design that's perfect for today's modern kitchen. The AquaPro digital water testers are the next generation for today's tech-savvy and health-conscience consumer.*

### FEATURES

- Measures total dissolved solids (TDS) and temperature.
- Automatic Temperature Compensation (ATC)
- Water-resistant housing
- Measurement Range: 0-5000 ppm
- Digital Calibration (push button)
- Auto-off function, data-hold function and low-battery indicator.
- Display: large and easy-to-read LCD screen includes simultaneous temperature reading.
- Factory Calibrated: The AquaPro is calibrated with a 342 ppm NaCl solution. The meter can be recalibrated with digital calibration using the push buttons, rather than a screwdriver.
- Includes a cap and batteries.
- Comes in a retail-oriented package.
- Magnetic body (patent pending)

### SPECIFICATIONS

**TDS Range:** 0-5000 ppm (mg/L)  
**Temperature Range:** 0-80 °C; 32-176 °F  
**Resolution:** 1 ppm  
**Temperature Resolution:** 0.1 °C/F  
**Accuracy:** +/- 2%  
**EC-to-TDS Conversion Factor:** NaCl (avg. 0.5)  
**Calibration:** Digital calibration by push button.  
**Housing:** Water-resistant  
**Power source:** 1 x 3V button cell (included) (model CR2032)  
**Dimensions:** 15 x 2.8 x 1.3 cm (5.9 x 1.1 x .5 inches)  
**Weight:** 42.5 g (1.5 oz)  
**PC:** 891144000120  
**U.S. PATENT D602,384S**



Keep the AquaPro on your fridge. It's magnetic!

**1 YEAR WARRANTY CE**

Distributed By:



2450 Business Park Drive, Vista, CA 92081, USA

(760) 727-3711 • FAX: (760) 727-4427

Internet: [www.appliedmembranes.com](http://www.appliedmembranes.com)

E-mail: [sales@appliedmembranes.com](mailto:sales@appliedmembranes.com)

